

BATTERY COVER REMOVAL:

The battery cover is designed to protect the internal components of the device, ensuring safety and compliance with regulatory standards such as Reese's Law. This law mandates secure battery compartments to prevent accidental access, particularly by children. Following these instructions will help you safely and efficiently remove the battery cover.

1 . Place the included 2.5mm hex wrench at a 45-degree angle to the pin protruding from the holes on the topside of the sight.



2 . Apply pressure with the hex wrench until you hear a click, indicating the pin has disengaged.



3 . To repeat on the second pin, turn the sight around and repeat the process for the second pin, applying pressure at a 45-degree angle until you hear a click.



4 . Once both pins have disengaged, you should be able to easily remove the battery cover.




BATTERY INSTALLATION:

Install battery into optic with the positive (+ = SHIELD logo) facing up.

When inserting, the battery must be tilted to make contact with the terminals as shown in fig.1, then pressed into place gently.

Failure to install the battery properly may bend the contacts and prevent operation. The battery life as stated is based on normal operating conditions. Extreme high and low temperatures will have an effect on battery life.

When replacing the CR2032 battery please remember to use one of our small, supplied battery stickers. This acts as a spacer and ensures solid connection with the terminals. You will also need to use a tool such as the included 1.5mm Hex Wrench to lever the battery out of the pocket via the recess as shown in fig.2



BATTERY WARNING

- a) This product contains a non-rechargeable battery
- b) Battery type (CR2032)
- c) Nominal Voltage 3V.

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Ensure the batteries are installed correctly according to polarity (+ and -).

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. **DO NOT** dispose of batteries in household trash or incinerate.

Even used batteries may cause severe injury or death. Non-rechargeable batteries are not to be recharged.

Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.